



Forney Corporation • 16479 North Dallas Parkway, Suite 600 • Addison, TX 75001 • Phone: 972.458.6100 • Fax: 972.458.6650

November 21, 2014

## Forney Explorer (FEX1) Notice

It has come to our attention that a recent Critical Update MS14-066 that was downloaded by Microsoft on November 14, 2014 for Windows 7 & 8 OS is causing the FEX1 software to become unstable.

During any "send data to scanner operation" from the software will cause a "Run-time error '48', File not found: SPCRC32.dll" message to be displayed and the software crashes.

Our software developer has been notified and is working on a possible solution.

If you uninstall the Critical Update the software returns to normal function. If your computer is not connected a network or the internet and you do not receive automatic updates from Microsoft, there should be no change in the function of the FEX1 software.

